

LOCKOUT/TAGOUT PROCEDURE OSHA CFR 1910.147

Developed by	Reviewed by	Revised by	
RA	RA		

Description: Peerless Pump 1 Equipment #: N/A

Building: Thompson Arena Area: Mechanical Room Revn: 0 Date: N/A Origin Date: 12/18/2017

3

Isolation Points to be Locked and Tagged

Safety Is Your Responsibility!



ALWAYS PERFORM A MACHINE STOP BEFORE LOCKING OUT DISCONNECTS

ID	Source	Device	Location	Method	Check			
4 E-1	Electrical 208V	Padlock	Isolation point located above unit.	Move electrical disconnect to off. Lock out.	Verify machine is deenergized.			
.≉ W-1	Condenser Water Suction - 40 PSI	Сар	Isolation point on East side of unit.	Disconnect line and install cap. Lock out.	Visually verify zero pressure status.			
.≉ W-2	Condenser Water Discharge - 40 PSI	Ball valve device	Isolation point on South side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.			



OPENING A GUARD DOES NOT CONSTITUTE A LOCKOUT

ALWAYS VERIFY DE-ENERGIZATION OF EXPOSED ELECTRICAL PARTS AND RESIDUAL CAPACITANCE

Any machine modifications must be shown in procedure. Contact EHS to update procedure: 603-646-1762

