Dartmouth Campus Services Facilities Operations & Management 6 Yox Lane, McKenzie Hall, Hannver, NH 03755	LOCKOUT/TAGOUT PROCEDURE OSHA CFR 1910.147			Revised by		
Description: Condenser Water Pump	Equipment #: CWP-2					
Building: North Chill Water Plant Area: No	Date: N/A	Origin Date:	12/18/2017			
Conception Deinte to be	DANGER					
3 Solation Points to be Locked and Tagged	Variable-frequency-drive capacitors often remain energized after shut-down. Discharge and wait 10 minutes prior to servicing.					

Safety Is Your Responsibility!



ALWAYS PERFORM A MACHINE STOP BEFORE LOCKING OUT DISCONNECTS

ID	Source	Device	Location	Method	Check
4 E-2	Electrical 480V			Move electrical disconnect "CWP-2" to off. Lock out.	Verify machine is deenergized.
<mark>,</mark> ₩ W-3	Condenser Water Suction - 40 PSI	Oublo	Isolation point on East side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.
. ™ W-4	Condenser Water Discharge - 40 PSI	000.0	Isolation point on West side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.



OPENING A GUARD DOES NOT CONSTITUTE A LOCKOUT

ALWAYS VERIFY DE-ENERGIZATION OF EXPOSED ELECTRICAL PARTS AND RESIDUAL CAPACITANCE Any machine modifications must be shown in procedure.

Contact EHS to update procedure: 603-646-1762

