

LOCKOUT/TAGOUT PROCEDURE OSHA CFR 1910.147

Developed by Reviewed by Revised by RA RA

Description: Condenser Water Filtration Pump Equipment #: CP-F-1


Building: South Chilled Water Plant | Area: Second Floor | Revn: 0 | Date: N/A | Origin Date: 12/18/2017

3 🎇

Isolation Points to be Locked and Tagged

Safety Is Your Responsibility!





ALWAYS PERFORM A MACHINE STOP BEFORE LOCKING OUT DISCONNECTS

ID	Source	Device	Location	Method	Check
4 E-1	Electrical 480V	Padlock	Isolation point located on panel MCC-1.	Move electrical disconnect "Basin Filter Pump" to off. Lock out.	Verify machine is deenergized.
₩ W-1	Filtration Water Suction - 100 PSI	Cable device	Isolation point on West side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.
.≉ W-2	Filtration Water Discharge - 100 PSI	Cable device	Isolation point on East side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.



OPENING A GUARD DOES NOT CONSTITUTE A LOCKOUT

ALWAYS VERIFY DE-ENERGIZATION OF EXPOSED ELECTRICAL PARTS AND RESIDUAL CAPACITANCE

Any machine modifications must be shown in procedure. Contact EHS to update procedure: 603-646-1762

