


## LOCKOUT/TAGOUT PROCEDURE OSHA CFR 1910.147

Developed by	Reviewed by	Revised by
RA	RA	

Description: Condensate Receiver Pump		Equipment #: CP-1	
Building: South Chilled Water Plant	Area: First Floor	Revn: 0	Date: N/A
		Origin Date: 12/18/2017	

<h3>3</h3>  <h3>Isolation Points to be Locked and Tagged</h3>	<h3>NOTE</h3>
	<p>This machine shares disconnects and removes sources from other equipment.</p>

## Safety Is Your Responsibility!





**East Side View**



**North Side View**



### ALWAYS PERFORM A MACHINE STOP BEFORE LOCKING OUT DISCONNECTS

ID	Source	Device	Location	Method	Check
	<b>Electrical 480V</b>	Padlock	Isolation point located above unit.	Move electrical disconnect to off. Lock out.	Attempt restart at CP-1.
	<b>Condensate Suction - 20 PSI</b>	Gate valve device	Isolation point on West side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.
	<b>Condensate Discharge - 20 PSI</b>	Ball valve device	Isolation point on North side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.
	<b>Thermal Energy 300 F</b>		Be sure to wait until heat has dissipated from machine until cool to touch before servicing. Wear proper PPE before beginning work.		



**OPENING A GUARD DOES NOT CONSTITUTE A LOCKOUT**  
ALWAYS VERIFY DE-ENERGIZATION OF EXPOSED ELECTRICAL PARTS AND RESIDUAL CAPACITANCE

Any machine modifications must be shown in procedure.  
Contact EHS to update procedure: 603-646-1762

