


**LOCKOUT/TAGOUT PROCEDURE
OSHA CFR 1910.147**

Developed by	Reviewed by	Revised by
RA	RA	

Description: Condenser Fan Ammonia System		Equipment #: EC-1	
Building: Thompson Arena	Area: Mechanical Room 110A	Revn: 0	Date: N/A Origin Date: 12/18/2017



1 	Isolation Point to be Locked and Tagged	DANGER
		Ammonia present. To be serviced by authorized personnel only. Wear proper PPE and ensure ventilation is adequate prior to servicing. Shut down adjacent equipment prior to servicing machine.

Safety Is Your Responsibility!

West Side View



ALWAYS PERFORM A MACHINE STOP BEFORE LOCKING OUT DISCONNECTS

ID	Source	Device	Location	Method	Check
	Electrical 480V	Padlock	Isolation point on West side of unit.	Move electrical disconnect to off. Lock out.	Verify machine is deenergized.
	Kinetic Energy 1800 RPM		Be sure to wait until all moving parts have come to a complete stop. If necessary, use a block or chain to prevent equipment from moving while servicing.		



OPENING A GUARD DOES NOT CONSTITUTE A LOCKOUT
 ALWAYS VERIFY DE-ENERGIZATION OF EXPOSED ELECTRICAL PARTS AND RESIDUAL CAPACITANCE
 Any machine modifications must be shown in procedure.
 Contact EHS to update procedure: 603-646-1762

