

## LOCKOUT/TAGOUT PROCEDURE OSHA CFR 1910.147

Developed by Reviewed by Revised by RA RA

Description: Glycol Pump Equipment #: CGP-1

Building: Thompson Arena Area: Mechanical Room Revn: 0 Date: N/A Origin Date: 12/18/2017

3 🍣

Isolation Points to be Locked and Tagged

## Safety Is Your Responsibility!

South Side View





## ALWAYS PERFORM A MACHINE STOP BEFORE LOCKING OUT DISCONNECTS

ID	Source	Device	Location	Method	Check
<b>4</b> E-1	Electrical 480V	Padlock	Isolation point on South side of unit.	Move electrical disconnect to off. Lock out.	Verify machine is deenergized.
<b>₹</b> V-1	Glycol Suction - 100 PSI	Padlock	Isolation point on South side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.
<b>→</b> V-2	Glycol Discharge - 100 PSI	Padlock	Isolation point located above unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.



OPENING A GUARD DOES NOT CONSTITUTE A LOCKOUT

ALWAYS VERIFY DE-ENERGIZATION OF EXPOSED ELECTRICAL PARTS AND RESIDUAL CAPACITANCE

Any machine modifications must be shown in procedure. Contact EHS to update procedure: 603-646-1762

