

**LOCKOUT/TAGOUT PROCEDURE**  
**OSHA CFR 1910.147**

Developed by	Reviewed by	Revised by
RA	RA	

Description: Glycol Pump		Equipment #: CGP-2	
Building: Thompson Arena	Area: Mechanical Room	Rev'n: 0	Date: N/A Origin Date: 12/18/2017

**3**  **Isolation Points to be Locked and Tagged**

**Safety Is Your Responsibility!**




**East Side View**



**North Side View**



**ALWAYS PERFORM A MACHINE STOP BEFORE LOCKING OUT DISCONNECTS**

ID	Source	Device	Location	Method	Check
 E-2	<b>Electrical 480V</b>	Padlock	Isolation point on South side of unit.	Move electrical disconnect to off. Lock out.	Verify machine is deenergized.
 V-3	<b>Glycol Suction - 100 PSI</b>	Padlock	Isolation point on South side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.
 V-4	<b>Glycol Discharge - 100 PSI</b>	Padlock	Isolation point located above unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.



**OPENING A GUARD DOES NOT CONSTITUTE A LOCKOUT**  
 ALWAYS VERIFY DE-ENERGIZATION OF EXPOSED ELECTRICAL PARTS AND RESIDUAL CAPACITANCE

Any machine modifications must be shown in procedure.  
 Contact EHS to update procedure: 603-646-1762

