

## LOCKOUT/TAGOUT PROCEDURE OSHA CFR 1910.147

Developed by	Reviewed by	Revised by
RA	RA	

Description: Peerless Pump 2 Equipment #: N/A

Building: Thompson Arena Area: Mechanical Room Revn: 0 Date: N/A Origin Date: 12/18/2017

3 🍣

Isolation Points to be Locked and Tagged

## Safety Is Your Responsibility!



## ALWAYS PERFORM A MACHINE STOP BEFORE LOCKING OUT DISCONNECTS

ALWATOT EN ONM A MACHINE STOT BEFORE ECONING OUT DISCONNECTS							
ID	Source	Device	Location	Method	Check		
<b>4</b> E-2	Electrical 208V	Padlock	Isolation point located above unit.	Move electrical disconnect to off. Lock out.	Verify machine is deenergized.		
; <b>∓</b> W-3	Condenser Water Suction - 40 PSI	Ball valve device	Isolation point on South side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.		
. <b>₩ W-4</b>	Condenser Water Discharge - 40 PSI	Ball valve device	Isolation point on South side of unit.	Turn valve to closed position.  Lock out.	Visually verify zero pressure status.		



## OPENING A GUARD DOES NOT CONSTITUTE A LOCKOUT

ALWAYS VERIFY DE-ENERGIZATION OF EXPOSED ELECTRICAL PARTS AND RESIDUAL CAPACITANCE

Any machine modifications must be shown in procedure. Contact EHS to update procedure: 603-646-1762

