

## LOCKOUT/TAGOUT PROCEDURE **OSHA CFR 1910.147**

Developed by Reviewed by Revised by RA RA

Description: Space Cooling Chiller Equipment #: CH-1

Building: Thompson Arena Area: Mechanical Room Revn: 0 Date: N/A Origin Date: 12/18/2017



### **CAUTION**


Pressurized refrigeration loop to be serviced by authorized personnel only.

# Safety Is Your Responsibility!

**North Side View** 







**South Side View** 



### ALWAYS PERFORM A MACHINE STOP BEFORE LOCKING OUT DISCONNECTS

ID	Source	Device	Location	Method	Check
<b>4</b> E-1	Electrical 480V	Breaker lockout device	Isolation point located in Electrical Room.	Move breaker "CH-1" to off. Lock out.	Attempt restart at CP-1.
<b>.</b> ₩ W-3	Chilled Water Inlet - 100 PSI	Padlock	Isolation point on East side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.
.# W-4	Chilled Water Outlet - 100 PSI	Padlock	Isolation point on East side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.
.≉ W-5	Condenser Water Inlet - 40 PSI	Cable device	Isolation point on East side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.
.≉ W-6	Condenser Water Outlet - 40 PSI	Cable device	Isolation point on East side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.
	Thermal Energy 200 F	<u> </u>	Be sure to wait until heat has dissipated from machine until cool to touch before servicing. Wear proper PPE before beginning work.		



#### OPENING A GUARD DOES NOT CONSTITUTE A LOCKOUT

ALWAYS VERIFY DE-ENERGIZATION OF EXPOSED ELECTRICAL PARTS AND RESIDUAL CAPACITANCE

Any machine modifications must be shown in procedure. Contact EHS to update procedure: 603-646-1762

