


**LOCKOUT/TAGOUT PROCEDURE**  
**OSHA CFR 1910.147**

Developed by	Reviewed by	Revised by
RA	RA	

Description: Space Cooling Chiller Compressor 1		Equipment #: N/A	
Building: Thompson Arena	Area: Mechanical Room	Revn: 0	Date: N/A
		Origin Date: 12/18/2017	

<b>2</b> 	<b>Isolation Points to be Locked and Tagged</b>	<b>CAUTION</b>
		Pressurized refrigeration loop to be serviced by authorized personnel only.

**Safety Is Your Responsibility!**




West Side View



East Side View



**ALWAYS PERFORM A MACHINE STOP BEFORE LOCKING OUT DISCONNECTS**

ID	Source	Device	Location	Method	Check
	Electrical 480V	Padlock	Isolation point on South side of unit.	Move electrical disconnect to off. Lock out.	Verify machine is deenergized.
	Chilled Water Inlet - 100 PSI	Padlock	Isolation point located above unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.
	Thermal Energy 200 F		Be sure to wait until heat has dissipated from machine until cool to touch before servicing. Wear proper PPE before beginning work.		



**OPENING A GUARD DOES NOT CONSTITUTE A LOCKOUT**  
ALWAYS VERIFY DE-ENERGIZATION OF EXPOSED ELECTRICAL PARTS AND RESIDUAL CAPACITANCE

Any machine modifications must be shown in procedure.  
Contact EHS to update procedure: 603-646-1762

