
Dartmouth Campus Services   Facilities Operations & Management 6 Vex Lane, McKenzie Hall, Hanaver, NH 03755	LOCKOUT/TAGOUT PROCEDURE OSHA CFR 1910.147		Developed by RA	Reviewed by	Revised by	
Description: Dehumidifier Air Handler Unit Equipment #: D					nt #: DH-1	
Building: Thompson Arena Area: Mezzanine Revn: 0			Revn: 0	Date: N/A	Origin Date:	12/18/2017
9 Solation Points to be Locked and Tagged		DANGER				
		Confined Space. Obtain proper permits and follow confined space procedure prior to entering. Variable-frequency-drive capacitors often remain energized after shut-down. Discharge and wait 10 minutes prior to servicing.				

## Safety Is Your Responsibility!





West Side View



## **ALWAYS PERFORM A MACHINE STOP BEFORE LOCKING OUT DISCONNECTS**

ID	Source	Device	Location	Method	Check		
<b>∲</b> E-1	Electrical 480V	Padlock	Isolation point on South side of unit.	Move electrical disconnect to off. Lock out.	Verify machine is deenergized.		
<mark>,#</mark> W-1	Chilled Water Inlet - 100 PSI	Padlock	Isolation point on South side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.		
<mark>양</mark> S-1	Steam Inlet - 20 PSI	Padlock	Isolation point on South side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.		
<mark>ଞ୍ଚି S-2</mark>	Steam Inlet - 20 PSI	Padlock	Isolation point on South side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.		
	Thermal Energy 300 F	m	Be sure to wait until heat has dissipated from machine until cool to touch before servicing. Wear proper PPE before beginning work.				
	Kinetic Energy 1800 RPM		Be sure to wait until all moving parts have come to a complete stop. If necessary, use a block or chain to prevent equipment from moving while servicing.				



OPENING A GUARD DOES NOT CONSTITUTE A LOCKOUT ALWAYS VERIFY DE-ENERGIZATION OF EXPOSED ELECTRICAL PARTS AND RESIDUAL CAPACITANCE



Dartmouth Campus Services   Facilities Operations & Management 6 Vux Lane, McKenzie Hall, Hanarver, NH 03755	LOCKOUT/TAGOUT PROCEDURE OSHA CFR 1910.147		Developed by RA	Reviewed by RA	Revised by	
Description: Dehumidifier Air Hand	Equipment #: DH-1					
Building: Thompson Arena Area: Mezzanine Revn: 0			Date: N/A	Origin Date:	12/18/2017	
		DANGER				
9 Solation Points Locked and Tage	prior to entering. Variable-free	Confined Space. Obtain proper permits and follow confined space procedure prior to entering. Variable-frequency-drive capacitors often remain energized after shut-down. Discharge and wait 10 minutes prior to servicing.				

## Safety Is Your Responsibility!

West Side View



South Side View



## ALWAYS PERFORM A MACHINE STOP BEFORE LOCKING OUT DISCONNECTS

ID	Source	Device	Location	Method	Check
<mark>,#</mark> W-2	Chilled Water Outlet - 100 PSI	Cable device	Isolation point on South side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.
<mark>.#</mark> W-3	Chilled Water Outlet - 100 PSI	Padlock	Isolation point on South side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.
<mark>,#</mark> W-4	Chilled Water Outlet - 100 PSI	Padlock	Isolation point on South side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.
<mark>쯍 S-3</mark>	Condensate Outlet - 20 PSI	Ball valve device	Isolation point on South side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.
<del>ଞ</del> S-4	Condensate Outlet - 20 PSI	Ball valve device	Isolation point on South side of unit.	Turn valve to closed position. Lock out.	Visually verify zero pressure status.



OPENING A GUARD DOES NOT CONSTITUTE A LOCKOUT ALWAYS VERIFY DE-ENERGIZATION OF EXPOSED ELECTRICAL PARTS AND RESIDUAL CAPACITANCE Any machine modifications must be shown in procedure.

Contact EHS to update procedure: 603-646-1762

